



How to Assemble an A Frame Picnic Table

Kit to include:



2 x A frame legs
2 x seat sections
1 x top
2 x diagonal sections
12 x 100mm bolts
12 x nuts and washers
12 x black nut caps
8 x 50mm wood screws

Tools required:

Hammer to tap bolts through
Pozzi 2 screw driver for the wood screws
13mm spanner to tighten nuts

Step one:



Bolt together one of the A frame legs to one of the seat sections using 2 x 100mm bolts. Add the washer and nut.

Do not fully tighten any of the nuts until all sections of the table have been put together.

Step two:



Fix the second A frame leg to the other end of the seat section you have just fitted using 2 x 100mm bolts, washers and nuts.

Step three:



Fix the picnic table top to the legs using 4 x 100mm bolts, washers and nuts.

Step four:



Fix the 2 diagonal pieces to the underside of the table top and to the A frame leg on each side using the 50mm wood screws.
NB. There are two pencil marks on the inside of the A frame to help guide placing.



Step five:



Fix the second seat section using the remaining bolts, nuts and washers. Now that the table is fully assembled, fully tighten all the bolts and nuts.

Step six:



Press the black caps onto the nuts.

Your table is now assembled. Enjoy using it!